
STAN P/S
STAN
3"/50 CAL AMMO MAGAZINE
5-139-0-M
WT
VL
DN
HWAY
3"/50 CAL HANDLING ROOM
5-135-0-M
MH
HQ
VL
FIRE ROOM
VOID
WT
MHO
CHAIN LKR SUMP
5-144-0-W
MH
STAN
MH
154
152
150
148
146
144
142
140
138
136
134
132
130
128
126
124
VOID
5-151-0-V
5-144-01-V
MH
MH
TRUNK
5-134-0-T
7-123-0-E
M
WT
VL
ORDNANCE STOREROOM
5-134-1-A
HWAY
DN
VL
MT ESCAPE TRUNK
5-133-1-T
WT
WT


FUEL OIL
OVERFLOW OR BALLAST
6-90-2-F
VL
MHO
OT
LUBE OIL
STOWAGE TANKS
5-110-6-F
5-110-4-F
5-110-2-F
MH
MT ESCAPE TRK
7-110-2-T
S D STOREROOM
5-100-0-A
STAN P/S
(PIPE BAR PLATE CABLE,
REEL & FOUNDRY STRM)
STAN
ENGINE ROOM
TANK TOP
20'-6" ABV ℄
PURE WATER TANK
5-98-4-W
PURE WATER TANK
5-98-2-W
WT
PURE WATER FACILITIES ROOM
5-96-2-Q
AT
S D STOREROOM
5-90-0-A
PASSAGE
5-95-2-L
SUB REPAIR PARTS
(NUCLEAR)
PLATF
DN
UP
HWAY
PASSAGE
5-97-2-L
CARGO ELEV #2
TRUNK
ELEVATOR
6-108-0-T
MT
ROOM
NUCLEAR TRUNK
7-94-0-T
CARGO TRUNK
6-94-1-T
NT
DECONTAMINATION
5-97-0-Q
122
120
118
116
114
112
110
108
106
104
102
100
98
96
94
92
90
STAN P/S
7-110-0-E
S D STOREROOM
5-90-3-A
UP
HATCH
PASSAGE
5-90-1-L
EM
STAN P/S
(SUBMARINE REPAIR PARTS)
PASSAGE
5- L
M
UP
DN
EM
VL
HWAY
STAN
FUEL OIL
OVERFLOW OR BALLAST
6-90-1-F
MHO
VL
MH
WT
OT
WT


FUEL OIL OVERFLOW OR BALLAST 6-80-2-F
VL
MHO
FUEL OIL OVERFLOW OR BALLAST 6-73-2-F
FUEL OIL OVERFLOW OR BALLAST 6-66-2-F
FUEL OIL OVERFLOW OR BALLAST 6-60-6-F
OT
WT
S D STOREROOM 5-80-0-A
SUBMARINE PERSONNEL LKR RM #5 5-76-2-A
SUBMARINE PERSONNEL LKR RM #4 5-70-2-A
SUBMARINE PERSONNEL LKR RM #3 5-64-4-A
SUBMARINE PERSONNEL LKR RM #2 5-60-2-A
SUBROC RECORDS OFF 5-57-2-Q
NTJ
PTJ
EM
PASSAGE 5-64-2-L
H WAY
UP
DN
PASSAGE 5-60-0-L
BATTERY STRM 5-63-2-A
AT
HYDRAULIC PACKAGE CHECK-OUT AREA 5-62-2-Q
STAN
MT
FBM ELEV TRK 7-60-2-T
SUBRO
UP DN PASSAGE 5-2-L
STORES CONV #5 7-85-2-T
NT
ELEV TRK 7-85-0-T
86, CARGO ELEV
FBM STOWAGE
7-68-0-M
88
84
82
80
78
76
74
72
70
68
66
64
62
60
58
NAV. EQUIP STOREROOM 5-61-1-A
ML
MJ
FAN ROOM (PLENUM) 5-60-1-Q
WORKS
5-49-
STAN P/S
(ELECTRONIC REPAIR PARTS)
HATCH
S D STOREROOM 5-60-3-A
STORES CONV #4 6-68-1-T
ACCESS TRK 6-60-3-T
BLO
B-
FUEL OIL OVERFLOW OR BALLAST 6-80-1-F
FUEL OIL OVERFLOW OR BALLAST 6-73-1-F
FUEL OIL OVERFLOW OR BALLAST 6-66-1-F
FUEL OIL OVERFLOW OR BALLAST 6-60-5-F


BLOWOUT TRUNK
8-57-2-T
FAN RM
MH
5-55-2-Q
MK 14/16 COMPONENT &
MK 65 MOD 0
EXERCISE HEAD STOW.
HATCH
PTJ
STAN P/S
5-49-4-A
WT
MH
TORPEDO BATT
CHARGING
SHOP & STRM
5-45-4-Q
STAN P/S
AT
MK 45 (ASTOR)
& MK 37
WORKSHOP
HATCH
VL
WT
STAN P/S
SECURITY ACCESS TRK
5-50-2-T
SUBROC MG RM
5-49-2-E
WT
HATCH
HWAY O
UP
VL
TORP RECORDS
OFF &
COMP TEST
RM 5-45-2-Q
STAN P/S
UP
HO
5-38-0-Q
C
TORPEDO ELEVATOR
7-47-0-T
56
54
52
50
48
46
44
42
40
38
36
34
32
30
26
24
HATCH
STAN
HOP
0-Q
STAN P/S
FREEZE STOREROOM (0°)
5-28-2-A
REFRIGERATION BHD
HATCH
DN
UP
AT
PASSAGE
5-28-0-L
STAN
STORES
CONV
#3
7-28-1-T
FREEZE STOREROOM (0°)
5-30-1-A
WARDROOM
FREEZE (0°)
5-28-1-A
SD STOREROOM
5-17-4-A
WT TRK 6-27-2-T
H&SO
VL
EMERGENCY
GEN RM
WT
WAY O
UP
ST
5-20-0-E
WT
SD STOREROOM
5-17-1-A
HATCH
WOUT TRUNK
57-1-T
MH
WT
WT
WT


LINE OF 4TH DK OVER
EM
PASSAGE
5-17-2-L
UP
DN
WT
ALCOHOL
STOREROOM
5-14-2-K
MJ
VL
ACID
STOREROOM
5-10-2-K
FOREPEAK
7-A-Q-W
℄ OF SHIP
VL
STORES
CONV
#2
6-17-0-T
DN
UP
HWAY
TAN
MJ
22
20
18
14
STAN
12
10
8
6
4
2
FP
WT
INACCESSIBLE
VOID
8-FP-0-V
STORES
CONV
#1
6-16-1-T
NT
FLAMMABLE
LIQUID STOREROOM
5-10-0-K
CHAIN LKR #
6-6-0-Q
CHAIN LKR #2
6-8-0-Q
WT
WT

AS 34-845-2105517

FIRST PLATFORM

SCALE - 1/16" = 1'-0"

PLATE 13 OF 17