
MH
STAN P/S
BOILER #2
BOILER #1
DN
UP
UP
MH
150
128
126
124
DEAERATING FEED TANK
FIRE ROOM
7-123-0-E
MH
MH
OT
WT
WT
MH
MH
STAN
ENGINE ROOM
MH
MH
STAN
STAN
MH
MH
122
120
118
116
114
112
110
108
STAN
7-110-0-E
STAN
MH
MH
STAN
STAN
MH
MH
MH
MH
MH
ESCAPE TRUNK
7-110-2-T
MT
VL
MT
STAN
STAN
MH
MH
OT
DIESEL
LUB OIL
(CARGO)
7-106-2-FF
OT
ELEV
PIT
TURBINE
LUB OIL
(CARGO)
7-106-0-F
VL
MHO
OT
OT
WT


FO OR BALLAST
8-80-4-F
OT
NT
OT
MH
NT
FO OR BALLAST
8-100-2-F
AO
CONTAMINATED
PARTS
STRM
7-97-0-A
FO OR BALLAST
8-90-2-F
S D STRM · MECH & ELEC
REPAIR PARTS
7-80-0-A
STAN
VL
VL
AO
MHO
STAN
OT
H WAY O
MH
MHO
MHO
VL
VL
H WAY O
MHO
AO
MH
AO
UP
AT
TRUNK
7-98-2-T
STAN
SUMP
COVER
HO
AO
STORES
CONVEYER #5
7-85-2-T
NT
NT
MT
AO
VL
OT
NUCLEAR
TRUNK
7-94-0-T
OT
STAN
MH
STAN
106
104
102
WT
98
96
AT
94
92
90
88
86
84
82
80
AO
VENT PLENUM
7-94-1-Q
AO
NT
MT
FO OR BALLAST
8-100-0-F
OT
SUMP COVER
STAN
CARGO
ELEV TRUNK
7-85-0-T
MH
CONTAM
LAUNDRY
TANK 7-97-3-W
FO OR BALLAST
8-90-0-F
AO
STAN
MH
AO
VL
MHO
VL
WT
AO
OT
MHO
STAN P/S
F
VL
OT
EFFLUENT
TANK 7-97-5-W
AO
P/S
STAN
VL
STAN
P/S
MH
FO OR BALLAST
8-100-1-F
O
WT
FO OR BALLAST
8-90-1-F
MHO
& VL
VL
MHO
P/S
EFFLUENT
TANK
7-97-7-W
WT
NT
AO
AO
P/S
VL
NT
MH
OT
OT
FO OR BALLAST
VOID
7-97-1-V
8-80-3-F
OT
OT
O
W


ACCESS & BLOW-OUT OPENINGS P/S
FO OR BALLAST 8-73-4-F
FO OR BALLAST 8-66-2-F
FO OR BALLAST 8-60-4-F
BLOW-OUT TRUNK 8-51-2-T
FO OR BALLAST 8-49-4-F
PYROTECHNICS MAGAZINE 7-73-2-M
SPECIAL CLOTHING STRM 7-60-6-A
SUBROC SPARE PARTS STRM 7-52-4-A
MK 14/16 COMP. STOWAGE STOREROOM 7-49-2-A
SUBROC IGNITER MAG 7-52-2-M
FBM STOWAGE AREA 7-68-0-M
PASS. 7-60-4-L
FBM ELEV 7-60-2-T
SUBROC MOTOR MAG 7-55-0-M
PASS 7-54-0-L
TORPEDO ELEVATOR 7-47-0-T
FBM TARGET. DATA CARD STRM 7-65-0-C
RE-ENTRY SYS. COMPONENT STRM 7-60-0-C
SUBROC GUIDANCE CONTROL AUX POWER UNIT STRM 7-49-1-A
OT BEL 6.567 LEV. WT ABV P/S
OT PLTG 6.567 ABV ℄ SHOWN NT PLTG 48 ABV ℄ BELOW
PUMP ROOM NO 2 7-60-1-E
S D STRM 7-71-1-A
SUBROC COMPONENT STOWAGE 7-52-1-A
STAN
STAN P/S
FO OR BALLAST 8-73-3-F
FO OR BALLAST 8-66-1-F
FO OR BALLAST 8-60-3-F
BLOW-OUT TRUNK 8-51-1-T
FO OR BALLAST 8-49-3-F
78 76 74 72 70 68 66 64 62 60 58 56 54 52 50
OT
NT
WT
MH
VL
HO
UP
EM
HWWO
HOSO


F O OVERFLOW OR BALLAST
MHO
8-38-4-F
LINE OF 2ND PLATF OVBR
OT
MK 37 & MK 45 COMPONENT STRM
7-38-2-A
FO OR BALLAST
8-28-6-F
MH & VL P/S
OT
MHO P/S
DIESEL OIL OR BALLAST (CARGO) 8-17-2-FF
8'-0" WA
OT
MH
HO
VL
MH
DRY PROVISION STRM
7-28-0-A
MH
VL
HES
MH
PUMP RM NO 1
MH
MK 37 & MK 45 ASTOR
STAN
STAN
ACCESS TRUNK 7-28-2-T
MH
VL
VL
48
46
44
42
40
38
36
34
32
30
28
26
24
22
20
18
TORPEDO BODY STOW
7-38-0-A
MH
WT
AC
WT
UNDERWATER LOG TRUNK 8-37-1-Q
STAN
7-17-0-E
STAN
MH
MH
STORES CONVEYER #3
7-28-1-T
MH
OT
MH
VL
WT
MH
MH
MK 37 & MK 45 COMPONENT STRM
7-38-1-A
HO
OT
OT
WASTE OIL TAN
7-21-1-F
OT
DIESEL OIL OR BALLAST (CARGO) 8-17-1-FF
OT
WT
OT
MHO P/S
FO OR BALLAST
8-28-3-F
FO OVERFLOW OR BALLAST
8-38-3-F
MHO
OT
WT


TER LINE
MO P/S
MHO
AO P/S
AO P/S
MHO
16
4
2
SUMP TANK
8-6-0-W
FORE PEAK
7-A-0-W
NT
NT
NT
OT
5
WT
FP
℄ OF SHIP
INACCESSIBLE VOID
8-FP-0-V
DIESEL OIL OVERFLOW
OR BALLAST
8-10-0-FF
NT FLAT
K

AS 34-845-2105517
HOLD
SCALE 1/16"=1'-0"
PLATE 15 OF 17